



JARD Pressure Switches

MARS SERIES **339**



Low Pressure Controls

Features:

- Tamper proof construction
- Direct mounting on tubing

Specifications:

- Contacts rated at 6 amps, 24-240 volts
- 1/4" female flare S.A.E. mounting
- 18" leads
- UL & CSA recognized

Low Pressure Controls, Open on Pressure Fall, Automatic Reset, Normally Open

FORMER MARS2 NO.	JARD NO.	DESCRIPTION	OPENING PRESSURE	RESET PRESSURE	MOUNTING
33929	43941	5/20 LP Open on fall	5	20	1/4" Female Flare Fitting S.A.E. Mounting
33930	43942	5/30 LP Open on fall	5	30	1/4" Female Flare Fitting S.A.E. Mounting
	43943	10/25 LP Open on fall	10	25	1/4" Female Flare Fitting S.A.E. Mounting
33933	43944	15/35 LP Open on fall	15	35	1/4" Female Flare Fitting S.A.E. Mounting
	43945	20/45 LP Open on fall	20	45	1/4" Female Flare Fitting S.A.E. Mounting
33962	43946	25/50 LP Open on fall	25	50	1/4" Female Flare Fitting S.A.E. Mounting
33936	43947	25/65 LP Open on fall	25	65	1/4" Female Flare Fitting S.A.E. Mounting
33963	43948	25/80 LP Open on fall	25	80	1/4" Female Flare Fitting S.A.E. Mounting
	43949	35/60 LP Open on fall	35	60	1/4" Female Flare Fitting S.A.E. Mounting
33964	43950	40/80 LP Open on fall	40	80	1/4" Female Flare Fitting S.A.E. Mounting
	43951	45/60 LP Open on fall	45	60	1/4" Female Flare Fitting S.A.E. Mounting
33939	43952	50/90 LP Open on fall	50	90	1/4" Female Flare Fitting S.A.E. Mounting
	43953	75/100 LP Open on fall	75	100	1/4" Female Flare Fitting S.A.E. Mounting
	43975	90/120 LP Open on fall	90	120	1/4" Female Flare Fitting S.A.E. Mounting
	43954	150/225 LP Open on fall	150	225	1/4" Female Flare Fitting S.A.E. Mounting
	43955	170/225 LP Open on fall	170	225	1/4" Female Flare Fitting S.A.E. Mounting



Condenser Fan Cycling Switch

Manual Reset high pressure controls

Specifications:

- UL & CSA recognized

FORMER MARS2 NO.	JARD NO.	DESCRIPTION	OPENING PRESSURE	RESET PRESSURE	MOUNTING	SWITCH ACTION (OPEN ON PRESSURE)
	43901	75/100 FC Close on rise	75	100	1/4" Female Flare Fitting S.A.E. Mounting	Fall
	43902	110/170 FC Close on rise	110	170	1/4" Female Flare Fitting S.A.E. Mounting	Fall
33940	43903	125/265 FC Close on rise	125	265	1/4" Female Flare Fitting S.A.E. Mounting	Fall
	43904	150/225 FC Close on rise	150	225	1/4" Female Flare Fitting S.A.E. Mounting	Fall
	43970	180/240 FC Close on rise	180	240	1/4" Female Flare Fitting S.A.E. Mounting	Fall
	43905	19/275 FC Close on rise	190	275	1/4" Female Flare Fitting S.A.E. Mounting	Fall
33941	43906	210/275 FC Close on rise	210	275	1/4" Female Flare Fitting S.A.E. Mounting	Fall
	43907	300/400 FC Close on rise	300	400	1/4" Female Flare Fitting S.A.E. Mounting	Fall
	43912	375/Man. Open on rise	375	Manual	1/4" Female Flare Fitting S.A.E. Mounting	Rise
	43913	410/Man. Open on rise	410	Manual	1/4" Female Flare Fitting S.A.E. Mounting	Rise
	43916	475/Man. Open on rise	475	Manual	1/4" Female Flare Fitting S.A.E. Mounting	Rise
33965	43911	410/290 HP Open on rise	410	290	1/4" Female Flare Fitting S.A.E. Mounting	Rise