



Ref.	Part Description	075-DV	100-DV	100-DVF
Solenoid				
1	Solenoid Handle	—	—	—
2	Solenoid Repair Kit	208588-01	208588-01	208588-01
3	Solenoid O-Ring	—	—	—
4	Solenoid Filter	—	—	—
BONNET				
5	Bonnet Assembly	—	—	—
6	Flow Control Handle	—	—	—
7	Bonnet with flow control	—	—	—
8	External Bleed Screw	—	—	—
9	Stem	—	—	—
10	Stem O-Ring	—	—	—
11	Piston	—	—	—
12	Piston O-Ring	—	—	—
13	Bonnet	—	—	—
14	DIAPHRAGM REPAIR KIT	210746-03	210746-03	210746-03
15	Bonnet screws (6)	—	—	—
16	Diaphragm Spring	—	—	—
17	Diaphragm Assembly w/Filter	—	—	—
—	Solenoid Filter	—	—	—
BODY				
18	Slip x Slip	—	—	—
—	NPT (not pictured)	—	—	—
—	BSP (not pictured)	—	—	—
—	Angle NPT (not pictured)	—	—	—
—	Angle BSP (not pictured)	—	—	—
—	Male x Male NPT (not pictured)	—	—	—
—	Male x Male BSP (not pictured)	—	—	—
—	1" Male NPT x 1" Barb (not pictured)	—	—	—
—	1" Male BSP x 1" Barb (not pictured)	—	—	—
—	1" Male NPT x 1 ³ / ₄ " Barb (not pictured)	—	—	—

Note: Part numbers enclosed in brackets () are not available individually, but may be sold in assemblies or kits.