

Furnace Replacement Parts

Furnace Replacement Parts (continued)

Control Assembly – 250, 350 & 500 Series

REF. NO.	DESCRIPTION	2509621	2509622	3509621	3509622	5009621	5009622
		2539621	2539622	3539621	3539622	5039621	5039622
		2559621	2559622	3559621	3559622	5059621	5059622
1	Wire Assembly (2 Required for 500 Series)	P321836	P321836	P321836	P321836	P321836	P321836
2	Valve	P322660	P323011	P322660	P323011	P322660	P323011
3	Front Burner Bracket	9B234	9B234	9B234	9B234	9B243	9B243
4	Manifold	P323660	P323660	P323660	P323660	P323661	P323661
5	Burner Orifice (2 Required for 500 Series)	P090554	P090543	P090554	P090538	P090554	P090544
6	Pilot/Generator Assembly	P501618	P501617	P501618	P501617	P322397	P322396
7	Thermostat	P322016	P322016	P322016	P322016	P322016	P322016
8	Burner (2 Required for 500 Series)	P323648	P323648	P323648	P323648	P323648	P323648
9	Electrode	P322276	P322276	P322276	P322276	P322155	P322155
10	Pilot Mounting Plate	-	-	-	-	9A409	9A409

Cabinet and Body Parts - 250 & 350 Series

REF. NO.	DESCRIPTION	2509621	2509622	3509621	3509622
		2539621	2539622	3539621	3539622
		2559621	2559622	3559621	3559622
1	Face Panel	4915	4915	4915	4915
2	Front Heat Shield	9C155	9C155	9C155	9C155
3	Combustion Chamber	6912	6912	6913	6913
4	Deflector	9B199	9B199	9B199	9B199
5	Inner Shield Top	9C153	9C153	9C153	9C153
6	Draft Hood	9C165	9C165	9C165	9C165
7	Vent Limit Switch	P321826	P321826	P322055	P322055
8	Shield Assembly	9C209	9C209	9C209	9C209
9	Header	5902	5902	5902	5902
10	Burner Pan	9B237	9B237	9B237	9B237
11	Heat Deflector	9A440	9A440	9A440	9A440
12	Manual Spark Igniter	P285500	P285500	P285500	P285500
13	Igniter Bracket	7A189	7A189	7A189	7A189
14	Pal Nut	P285501	P285501	P285501	P285501
**	Header - Insulation	P310000	P310000	P310000	P310000
**	Parts Bag	9A288-1	9A288-1	9A228-1	9A228-1
**	Knob	P332606	P332606	P332606	P332606
**	Vent Limit Switch Bracket	P322074	P322074	P332074	P332074

** Not Shown