



WASHING MACHINE VALVES

BULK	BARCODED	DESCRIPTION	BAG	CASE
06886	16886	FLAIR-IT WASH MACH VALVE 1/2" MPT X HOSE BIBB WASH MACH	10	100
06887	16887	FLAIR-IT WASH MACH VALVE 1/2"	10	100



MANIFOLD VALVES

BULK	BARCODED	DESCRIPTION	BAG	CASE
06916	16916	FLAIR-IT MANIFOLD VLVE 1/2" FSWV X 1/2" MPT X 1/2" MPT (RED)	10	100
06917	16917	FLAIR-IT MANIFOLD VLVE 1/2" FSWV X 1/2" MPT X 1/2" MPT (BLUE)	10	100



ANGLE DRAIN VALVES

BULK	BARCODED	DESCRIPTION	BAG	CASE
06916	16916	FLAIR-IT MANIFOLD VLVE 1/2" FSWV X 1/2" MPT X 1/2" MPT (RED)	10	100
06917	16917	FLAIR-IT MANIFOLD VLVE 1/2" FSWV X 1/2" MPT X 1/2" MPT (BLUE)	10	100



CENTER DRAIN VALVES

BULK	BARCODED	DESCRIPTION	BAG	CASE
06882	16882	FLAIR-IT ANGLE DRAIN VALVE 3/8"	10	100
06884	16884	FLAIR-IT ANGLE DRAIN VALVE 1/2"	10	100



WATER HEATER BYPASS VALVES

BULK	BARCODED	DESCRIPTION	BAG	CASE
06900	16900	FLAIR-IT 3-WAY WTR HTR BYPASS VALVE 3/8"	10	100
06910	16910	FLAIR-IT 3-WAY WTR HTR BYPASS VALVE 1/2"	10	100
06912	16912	FLAIR-IT 3-WAY WTR HTR BYPASS VALVE 1/2" X 1/2" MPT X 1/2"	10	100
06913	16913	FLAIR-IT 3-WAY WTR HTR BYPASS VALVE 1/2" X 1/2" FPT SWV X 1/2"	10	100



WATER HEATER BYPASS KIT PARTS AND FLEX TUNING ADAPTERS

BULK	DESCRIPTION
06313	1/2" FLEXIBLE BRAIDED TUBING NUT
06325	1/2" FLEX TUBING NUT AND INSERT
06783	1/2" FLEXIBLE PIPE ADAPTER
04914	BRASS CHECK VALVE 1/2" MPT X 1/2" MPT
04915	BRASS NIPPLE 1/2" MPT X 2"
04929	Plastic Check Valve 1/2" MPT X 1/2" MPT



RV WATER HEATER BYPASS KITS

BULK	DESCRIPTION
04912	FLAIR-IT RV WATER HEATER BYPASS KIT
04917	FLAIR-IT SUPREME RV WATER HEATER BYPASS KIT W/ 1 VALVE



FLEX TUBING ADAPTERS

CHECK VALVES