



**Model/Modelo/Modèle**  
**776-LHP-DST**  
**Series/Series/Seria**  
**STRYKE™**


**RP71111 (0.5)**  
**RP72730 (1.0)**  
**RP70933-1.2**  
 Aerator & Wrench  
 Aereador y Llave  
 Aérateur et Clé




**RP91902**  
 Valve Assembly  
 Ensamble de la válvula  
 Soupape




**RP91903▲**  
 Bonnet Nut & Cap  
 Tuerca tapa y Tapa  
 Écrou-chapeau et  
 capuchon



**RP100359▲**  
 Gasket (1 Hole Only)  
 Empaque (1 agujero solo)  
 Joint (1 trou seulement)



**RP47029**  
 Mounting Bracket  
 Abrazadera  
 Support



**RP47030**  
 Nut & Wrench Assembly  
 Ensamble de Tuerca y Llave  
 Écrou et clé


**RP51243**  
 Gaskets  
 Empaques  
 Joints




**RP50952**  
 Plastic Sleeves  
 Mangas Plásticas  
 Manchons en plastique



**H550▲**  
 Handle Assembly  
 El ensamble de la manija.  
 Manette



**H551▲**  
 Handle Assembly  
 El ensamble de la manija.  
 Manette



▲Specify Finish / Especificque el Acabado / Précisez le Fini