



Models/Modelos/Modèles

35897LF ▲


Series/Series/Seria

Esato™




**RP101058**  
1.2 GPM (4.5 L/min)  
Aerator & Wrench  
Aireador y Llave  
Aérateur et Clé


**RP101938▲**  
Gasket  
Empaque  
Joint




**RP101936▲**  
Handle Assemblies  
Conjunto de manija  
Montage de la manette




**RP101069**  
Stem Unit Assembly, Seat & Spring,  
Bonnet Nut  
Ensamble de la Unidad del Vástago,  
Asiento y Resorte, Bonete  
Obturateur, siège et ressort, écrou à  
chapeau



**RP101549▲**  
Gasket  
Empaque  
Joint




**Springloaded Pop-up**  
(includes drain plug)  
**tapón a resorte**  
(incluye el tapón de desagüe)  
**Bouton à ressort**  
(inclus le bouchon de vidange)



**RP47423**  
Washers (2), Nuts (2)  
& Screws (4)  
Arandelas (2), Tuercas (2)  
y Tornillos (4)  
Rondelles (2), Écrous (2)  
et Vis (4)

**RP93980**  
Hose Assembly  
Ensamble de la manguera  
Tuyau souple



**RP50652▲**  
Gasket, Nut &  
Washer Kit  
Juego de Junta,  
Tuerca y  
Arandela  
Jeu de joint,  
écrou et rondelle

▲ Specify Finish / Especificque el acabado / Précisez la Finition