




## Model XPH01,XPH01CW,XPH01RW,XPH01Z Parts List

A = Standard Equipment

O= Circuit Diagram

| Item# | Part#        | Description                    | Q'ty  | Unit                    |
|-------|--------------|--------------------------------|-------|-------------------------|
| 001   | 815C82-5     | XPH01 NAME PLATE               | 1     | XPH01, XPH01Z           |
|       | 802R26-4     | XPH01CW NAME PLATE             | 1     | XPH01CW                 |
|       | 804V36-1     | XPH01RW NAME PLATE             | 1     | XPH01RW                 |
| 002   | 188971-2     | HOUSING SET                    | 1 PC. | XPH01, XPH01Z           |
|       | 188970-4     | HOUSING SET                    | 1 PC. | XPH01CW, XPH01RW        |
|       | C10 263005-3 | RUBBER PIN 6                   | 2 PC. |                         |
|       | D10          | INC. 19                        |       |                         |
| 003   | 266429-2     | TAPPING SCREW 3X16             | 9 PC. |                         |
| 004   | 126289-3     | SPEED CHANGE LEVER ASSEMBLY    | 1 PC. |                         |
|       | C10 233438-6 | COMPRESSION SPRING 4           | 2 PC. |                         |
| 005   | 419250-0     | F/R CHANGE LEVER               | 1 PC. |                         |
| 006   | 650731-7     | SWITCH C3HZ-1A-TLMS            | 1     |                         |
| 007   | 620012-3     | LED CIRCUIT                    | 1 PC. |                         |
| 008   | 643852-2     | TERMINAL                       | 1 PC. |                         |
| 009   | 251468-5     | - FLAT HEAD SCREW M6X22        | 1 PC. |                         |
| 010   | 766008-1     | KEYLESS DRILL CHUCK 13         | 1 PC. |                         |
| 011   | 126460-9     | GEAR ASSEMBLY                  | 1     |                         |
| 012   | 638425-4     | YOKE UNIT                      | 1 PC. |                         |
| 013   | 619263-3     | ARMATURE                       | 1 PC. |                         |
| 014   | 638494-5     | BRUSH HOLDER COMPLETE          | 1 PC. |                         |
| 015   | CB440        | CARBON BRUSH CB-440 (195021-6) | 1 SET |                         |
| 016   | 263032-0     | RUBBER PIN 4                   | 2 PC. |                         |
| 017   | 452205-2     | REAR COVER                     | 1 PC. | XPH01, XPH01Z           |
|       | 452202-8     | REAR COVER                     | 1 PC. | XPH01CW, XPH01RW        |
| 018   | 266429-2     | TAPPING SCREW 3X16             | 2 PC. |                         |
| 019   | 188971-2     | HOUSING SET                    | 1 PC. | XPH01, XPH01Z           |
|       | 188970-4     | HOUSING SET                    | 1 PC. | XPH01CW, XPH01RW        |
|       | C10 263005-3 | RUBBER PIN 6                   | 2 PC. |                         |
|       | D10          | INC. 2                         |       |                         |
| 020   | 232182-2     | LEAF SPRING                    | 1 PC. |                         |
| 021   | 689170-4     | HEAT SINK                      | 1 PC. |                         |
| 022   | 911013-5     | PAN HEAD SCREW M3X10           | 1 PC. |                         |
| 023   | 802P77-5     | CAUTION LABEL                  | 1     |                         |
| 024   | 424476-1     | CUSHION                        | 1 PC. |                         |
| A01   | 251314-2     | + SCREW M4X12                  | 1 PC. | XPH01, XPH01CW, XPH01RW |
| A02   | 346449-3     | HOOK                           | 1 PC. | XPH01, XPH01CW, XPH01RW |
| A03   | 784637-8     | + - BIT 2-45                   | 1 PC. | XPH01, XPH01CW, XPH01RW |
| A04   | 142146-7     | PLASTIC CASE COMPLETE          | 1 PC. | XPH01                   |
|       | 141856-3     | PLASTIC CASE COMPLETE          | 1 PC. | XPH01CW, XPH01RW        |
|       | C10 162302-3 | LATCH                          | 2 PC. | XPH01CW, XPH01RW        |
|       | C20 324207-7 | SHAFT                          | 1 PC. | XPH01CW, XPH01RW        |
|       | C30 451749-9 | HANDLE                         | 1 PC. | XPH01CW, XPH01RW        |
| A05   | 450128-8     | BATTERY COVER                  | 1 PC. | XPH01, XPH01CW          |
| A06   | ***DC18RC    | DC18RC FAST CHARGER            | 1 PC. | XPH01, XPH01CW, XPH01RW |
| A07   | BL1830       | BATTERY BL1830 SET             | 2 SET | XPH01                   |
|       | BL1815       | BATTERY BL1815 SET             |       | XPH01CW                 |
|       | BL1820       | BATTERY BL1820 SET             |       | XPH01RW                 |