

## RP 330 Pressing Tools

### Cleaning and Lubrication

1. Daily wipe the tool clean with a clean dry cloth.
2. Inspect the attachment mounting pin and lubricate the pin with silicone lubricant as needed.
3. Check return springs in attachments with each use. Attachments should open and close freely with only moderate finger effort required.

### Required Maintenance at RIDGID Authorized Service Center

After 30,000 cycles, the tool will show a blinking yellow LED on the display panel as long as the tool is turned on to indicate that it is time for maintenance and recalibration. The tool will not run if it is not maintained within 2,000 more cycles after the yellow blinking LED begins.

## Accessories

### **⚠ WARNING**

**Only the following tool accessories have been designed to function with the RP 330 Pressing Tools. Other accessories suitable for use with other tools may become hazardous when used on the RP 330. To prevent serious injury, use only the accessories specifically designed and recommended for use with the RP 330, such as those listed below.**

**Ridge Tool Company provides Standard Pressing attachments designed specifically for use with RIDGID Standard Pressing tools. Only use attachments that are specifically designed to press the fitting system you are installing. For a complete listing of RIDGID attachments available for this tool, see the Ridge Tool Catalog on line at [www.RIDGID.com](http://www.RIDGID.com) or call Ridge Tool Technical Services (800) 519-3456.**

### RP 330 Press Tool Accessories

Catalog No.	Description
27968	18V Lithium-Ion Battery Pack 2.2Ah
27958	115V Charger
27933	Carrying Case (Plastic)

## Storage

Place the tool and jaws in its carrying case. Avoid storing the tool, batteries or charger in extreme heat or cold. The tool temperature sensor will not allow the tool to turn on if oil temperature is not within the temperature range of 15°F (-10°C) to 122°F (50°C). So it may be necessary to allow the tool to warm or cool to a temper-

ature within the operating range by placing it in a conditioned room for several minutes before use. This will be indicated by a red glowing LED on the display panel.

**⚠ WARNING** Store the carrying case in a dry, secured, locked area that is out of reach of children and people unfamiliar with the RP 330 Pressing Tool. The tool is dangerous in the hands of untrained users.

## Service and Repair

### **⚠ WARNING**

**Improper service or repair can make machine unsafe to operate.**

Service and repair on this RP 330 Pressing Tool must be performed by a RIDGID Authorized Service Center. The tool fasteners have been marked to indicate if service has been performed by unauthorized individuals.

For information on your nearest RIDGID Independent Service Center or any service or repair questions:

- Contact your local RIDGID distributor.
- Visit [www.RIDGID.com](http://www.RIDGID.com) or [www.RIDGID.eu](http://www.RIDGID.eu) to find your local RIDGID contact point.
- Contact RIDGID Technical Services Department at [rtctechservices@emerson.com](mailto:rtctechservices@emerson.com) or in the U.S. and Canada call (800) 519-3456