

REPLACEMENT PARTS FOR MODELS
4505621 4505622 6005621 6005622

KEY NO.	DESCRIPTION	4505621	4505622	6005621	6005622
1	GRILLE, FLOOR	P322428	P322428	P322429	P322429
2	INNER LINER ASSY	4B0041	4B0041	4B0042	4B0042
3	L.H. SECONDARY CHAMBER	4B0056-1	4B0056-1	4B0057-1	4B0057-1
4	COMBUSTION CHAMBER	4B0046	4B0046	4B0047	4B0047
5	R.H. SECONDARY CHAMBER	4B0056-2	4B0056-2	4B0057-2	4B0057-2
6	OUTER SHIELD ASSY	4B0036	4B0036	4B0069	4B0069
7	PEEP HOLE COVER ASSY	12B40	12B40	12B40	12B40
8	IGNITOR	P285500	P285500	P285500	P285500
9	SWITCH, LIMIT	P322430	P322430	P322430	P322430
10	KEY, CONTROL	P322445	P322445	P322445	P322445
11	ROD, CONTROL	4A0037	4A0037	4A0037	4A0037
12	ROD, LIGHTER	P322431	P322431	P322431	P322431
13	WRE, THERMOSTAT	P017000	P017000	P017000	P017000
14	THERMOSTAT	P322016	P322016	P322016	P322016
15	CONTROL VALVE NAT.	—————	P322425	—————	P322425
	CONTROL VALVE L.P.G.	P322426	—————	P322426	—————
16	BRACKET, VALVE	4B0019	4B0019	4B0019	4B0019
17	MANIFOLD ASSY	4A0012	4A0012	4A0012	4A0012
18	PILOT NAT.	—————	P322274	—————	P322274
	PILOT L.P.G.	P322275	—————	P322275	—————
19	SHIELD, BURNER	4B0014	4B0014	4B0010	4B0010
20	BURNER	P322417	P322417	P322418	P322418
21	GASKET, FLUE OUTLET	P322439	P322439	P322439	P322439
22	DRAFTHOOD COLLAR ASSY	4B0072	4B0072	4B0072	4B0072
23	DRAFTHOOD ASSY	4B0026	4B0026	4B0026	4B0026
24	ENVELOPE ASSEMBLY	4B0024	4B0024	4B0024	4B0024

FOR PARTS ILLUSTRATION, SEE PAGE 17
USE ONLY MANUFACTURES AUTHORIZED PARTS

NOTE: Screws, bolts and washers are standard hardware items and may be purchased locally