

Replacement Parts List

Enclosed Front

Key No.	Description	3501522	3501521	5001522	5001521	6501522	6501521
		3531522	3531521	5031522	5031521	6531522	6531521
		3551522	3551521	5051522	5051521	6551522	6551521
		3501922	3501921	5001922	5001921	6501922	6501921
		3531922	3531921	5031922	5031921	6531922	6531921
		3551922	3551921	5051922	5051921	6551922	6551921
1	Panel Side Right	K000204	K000204	K000205	K000205	K000206	K000206
2	Thermostat	P322016	P322016	P322016	P322016	P322016	P322016
3	Inlet Duct	K7000-6022	K7000-6022	K7000-6022	K7000-6022	K7000-6022	K7000-6022
4	Bottom Louver Assembly	K000182-1	K000182-1	K000182-2	K000182-2	K000182-3	K000182-3
5	Center Panel	K000220	K000220	K000221	K000221	K000222	K000222
6	Cabinet Bottom	K5000-6003	K5000-6003	K5000-6004	K5000-6004	K5000-6019	K5000-6019
7	Panel Side Left	K000207	K000207	K000208	K000208	K000209	K000209
8	Wire Assembly	P500409	P500409	P500416	P500416	P500416	P500416
9	Top Louver Assembly	K000181	K000181	K000212-1	K000212-1	K000212-1	K000212-1
10	Combustion Chamber	K000079	K000079	K000041	K000041	K000045	K000045
11	Burner	P501620	P501620	P501621	P501621	P501622	P501622
12	Cabinet Top	K000223	K000223	K000224	K000224	K000225	K000225
13	Control Bracket	K000147	K000147	K000147	K000147	K000147	K000147
14	Orifice	P500080	P500081	P500082	P500083	P500084	P500085
15	Orifice Fitting	P500086	P500086	P500086	P500086	P500086	P500086
16	Manifold Pipe	P500087	P500087	P500088	P500088	P500089	P500089
17	Gas Control Valve	P323011	P322660	P323011	P322660	P323011	P322660
18	Electrode Igniter	P322276	P322276	P322276	P322276	P322276	P322276
19	Shield Cover	-	-	K7011-6030	K0711-6030	K0711-6031	K0711-6031
20	Pilot & Generator Assembly	P322274	P322275	P322274	P322275	P322274	P322275
21	Vent Safety Switch	P500472	P500472	P500406	P500406	P500118	P500118
22	Heat Shield (Rear)	K7003-6370	K7003-6370	K7003-6371	K7003-6371	K7003-6372	K7003-6372
23	Back Plate	K000226	K000226	K000227	K000227	K000228	K000228
24	Rear Corner Brace	K7003-6097	K7003-6097	K7003-6097	K7003-6097	K7003-6097	K7003-6097
25	Bracket	7A189	7A189	7A189	7A189	7A189	7A189
26	Manual Spark Igniter	P285500	P285500	P285500	P285500	P285500	P285500

Note: Screws, bolts and washers are standard hardware items and may be purchased locally.

Enclosed Front

